





WEW AGHAT BRIN & NECK CURTAIN COMBO FOR GREATER SUN



PROTECTION...



Remove velcro strip from rear underside of brim [illustration 1].



Remove adhesive backing from velcro strip [illustration 2].



Re-position Safety Standard label and fix velcro strip to centre rear of AgHat helmet, just above lower edge, with strip running vertically [illustration 3].



NEW!

To fit brim/neck curtain combo to AgHat helmet, insert front peak of helmet into pocket of front underside of brim [illustration 4].



GREATER

PROTECTION FROM HARMFUL UV RAYS

Pull brim/neck curtain combo down over rear of helmet and attach velcro strip on underside of curtain to velcro on rear of AgHat helmet [illustration 5].